

10x20 Gorilla Grow Tent







Place roof onto tent frame.

Align the zipper stops in the front and back of floor with the terminations on the roof. Carefully guide each corner of the roof over each corner of the frame a little at a time. This will allow plenty of slack to properly fit the corners. Do not fully seat the roof at one corner and attempt to stretch corners over frame. Do not use excessive force. Doing so may damage your tent and void warranty.



^{*}Your tent may differ slightly from this graphic.

5 Starting at the back of the tent add & zip extension skirt *If you do not plan on using the height extension, skip to Step 6



*Your tent may differ slightly from this graphic.

Zipper Detail



Bring tent wall to Velcro assist strips then zip tent.



Add Roof Support Beams. Position E poles, then F pole. Add Noor Correct E poles are load bearing. LOAD BEARING BARS LOAD BEARING BARS Gorilla LOAD BEARING BARS Õ • Place spill pool on floor of tent and secure Velcro straps around poles. Gorilla VELCRC SECURE CENTER POLE SPILL POOL HOLE CENTER POLE SPILL POOL HOLE CENTER POLE

WWW.GORILLAGROWTENT.COM 1-855-G4G4T8-G4R708W