





GGTCL18 & GGTCL24 INSTRUCTIONS


1. UNBOX




2. CHECK COMPONENTS




1X
TENT



3. UNFOLD




FRONT



BACK

4. ASSEMBLE FRAME




5. TENT COVER

Place tent cover on a flat surface and unzip completely.


Slide in tent frame, making sure it seats in the bottom of the cover.

Carefully guide each corner of the roof over the frame a little at a time. This will allow the necessary slack to properly fit the corners.

Do not fully seat the roof at one corner and then attempt to stretch over the rest of the frame. Do not use excessive force, as doing so may damage your tent and void the warranty.




6. ROOF SUPPORTS



Locate the E & F poles. The E pole will hang from the A poles and the F pole will hang from the D poles. As fitment is designed to be tight, it can help to insert at an angle and then adjust to the correct position.

NOTE:

When viewing from the top, the E pole should be positioned over the F pole.





YOU ARE NOW READY TO
**CLONE
STRONG.**

BE SURE TO FOLLOW US ON SOCIAL
AND TAG US IN YOUR EPIC GROW POSTS



@gorillagrowtent

#CLONESTRONG

#GROWSTRONG #GORILLAGROWTENT